

Enable-IT 350 Power over Ethernet Injector User Manual



Copyright © 1997- 2008, Enable-IT, Inc. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from Enable-IT, Inc.

Enable-IT, Inc reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of Enable-IT, Inc to provide notification of such revision or change.

Enable-IT, Inc provides this documentation without warranty, term, or condition of any kind, either implied or expressed, including, but not limited to, the implied warranties, terms or conditions of merchantability, satisfactory quality, and fitness for a particular purpose. Enable-IT, Inc may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this documentation, it is furnished under a license agreement included with the product as a separate document, in the hard copy documentation. If you are unable to locate a copy, please contact Enable-IT, Inc and a copy will be provided to you.

UNITED STATES GOVERNMENT LEGEND

If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:

All technical data and computer software are commercial in nature and developed solely at private expense. Software is delivered as "Commercial Computer Software" as defined in DFARS 252.227-7014 (June 1995) or as a "commercial item" as defined in FAR 2.101 (a) and as such is provided with only such rights as are provided in Enable-IT, Inc's standard commercial license for the Software.

Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with, this User Guide.

Unless otherwise indicated, Enable-IT, Inc registered trademarks are registered in the United States and may or may not be registered in other countries

CONTENTS

ABOUT THIS GUIDE	4
1 INTRODUCING THE ENABLE-IT 350 KIT	5
About the 350 Power Over Ethernet Injector	5
Key Benefits	6
Summary of Features	6
Product Specifications	6
Typical Applications	7
2 INSTALLING THE ENABLE-IT 350 KIT	8
Unpacking the 350 Power Over Ethernet Injector	8
Performing the On-Site Installation	8
A TECHNICAL SUPPORT	9
Online Technical Services	9
World Wide Web Site	9
Returning Products for Repair	9
B Enable-IT Inc. LIMITED WARRANTY	10


ABOUT THIS GUIDE

This guide provides all the information needed to install and use the Enable-IT 350 Power Over Ethernet Injector. This guide is intended for use by technicians who are responsible for installing and setting up network equipment. Consequently, it is assumed that the installer has a basic working knowledge of LANs (Local Area Networks) and voice telecom wiring.

If the information in the release notes that are shipped with your product differs from the information in this guide, follow the instructions in the release notes.

Most user guides and release notes are available in Adobe Acrobat

Reader Portable Document Format (PDF) or HTML on the Enable-IT World Wide Web site: http://www.ethernetextender.com/manuals/350_manual.pdf

A decorative graphic consisting of a thick, light gray curved line that starts from the left edge of the page and curves upwards and to the right, ending in a large, light gray sphere.

INTRODUCING THE 350 POWER OVER ETHERNET INJECTOR

Congratulations on purchasing the Enable-IT's 350 Power Over Ethernet Injector — the simplest to enable your Power Over Ethernet devices.

The 350 Power Over Ethernet Injector offers a low cost single port solution in a simple design for rapid install using existing Ethernet cabling.

This chapter contains introductory information about The 350 Power Over Ethernet Injector and how it can be used in your network. It covers the following topics:

- About the 350 Power Over Ethernet Injector
- Key Benefits
- Summary of Features
- Typical Applications

About the 350 Power Over Ethernet Injector

The 350 Power Over Ethernet Injector solves the problem of high costs associated with adding additional electrical outlets in hard to reach places for your LAN equipment such as Wireless Access points or security cameras.

Power-Over-Ethernet (PoE) Compatible

The 350 is a Compact IEEE 802.3af standard Power Over Ethernet Injector which provides 48 VDC over any wiring and up to unexpected extended distance. The units are fully compatible with industry-standard IEEE 802.3af Power-over-Ethernet (PoE) devices and 10/100 Base-T Ethernet networks, providing both Ethernet data pairs as well as the PoE DC power feed.

48 Volts are applied on pins 4, 5, 7 and 8 in separate lines not bridged. The units are compatible with both normal and inverted polarity voltage PoE equipment.

For maximum distance, PoE travels very very far down any type of wiring. Voltage drops over distance using wires. At 200M, you lose maybe 4 or 6 volts. At 48VDC, that leaves you with 42 volts. You can determine the amount of voltage drop over a distance by finding the resistance of the cable for a specific temperature (given in ohms/1000ft) from the cable manufacturer or electrical wholesaler. If you know the largest amount of current that will flow in the cable, when use the formula: $V_{drop} = \text{Current} \times \text{Distance (Ft)} \times 2 \times \text{Ohms per 1000Ft}$.

As a rule of thumb you will loose 6V per every 100' - 200' of wiring, depending on the gauge. Lower power also means more amperage means more heat and perhaps issues with the 24 gauge wires in CAT5. You may need to use 18 gauge wiring. For all intensive purposes anything greater than 400' use a 48V POE.

Keep in mind that Ethernet data has a limit of 328ft or 100m. You can easily solve this issue by using the Enable-IT 350 PoE Injector with an Enable-IT 820 Super PoE Ethernet Extender kit. Using the 820 kit will drive your PoE and data up to 800ft.

Key Benefits

The following list identifies the 350 Power Over Ethernet Injector key benefits.

- Provides 48VDC PoE to any IEEE802.3af devices at great distances*.
- Rapid installation with small box profile, no programming and no firmware to upgrade. Maintains existing RJ-45 Ethernet Data.

The Enable-IT™ 350 48VDC Power over Ethernet Injector is single port IEEE 802.3af compliant Midspan solution that is a compact and easy to install with RJ-45 Ethernet cabling. This elegant unit is ideal for installing any WiFi Wireless Access Point, Security camera or other PoE powered equipment. It eliminates the need for external power supply and its associated AC/DC power cabling, providing a compact, affordable, safe and reliable power solution over your wiring or existing Ethernet infrastructure.

Summary of Features

The Enable-350 Power Over Ethernet Injector has the following hardware features:

- 48 VDC Output 802.3af Power Over Ethernet Injector
- 19W, Cispr 22'B', VCCI 'B', FCC 'B' Compliance.
- Rapid installation - no programming required.
- Maintains existing RJ-45 Ethernet Data.
- Supports VoD (Video on Demand) and MPEG IP channels.
- Supports VoIP (Voice over IP).
- Network Equipment independence - Transparent to protocols/applications/MAC.

The Enable-IT 350 PoE Injector can be used with the Enable-IT 380 PoE Range Extender/s to drive your full PoE strength up to 7,200ft.

Product Specifications

- Power
48 V, .04A - AC input 90 ~ 264V
- Data Rate
100Mbps full-duplex
- Interface
Ethernet: RJ-45 Standard
- Dimensions
Height 3" (85mm) Depth 1.5" (40 mm) Width 2"(60mm)
- Environment
Operational Temperature : 13°-140°F (-25°-60°C)
Humidity: 5%-90%, non-condensing
- Enclosure
Square plastic casing with dual RJ-45 Network ports

Typical Applications

Enable-IT 350 Power Over Ethernet Injector unit is very lightweight and compact for most all applications and use. These units are easy and rapid to install with plug and play RJ-45 Ethernet jacks to quickly insert your wiring and go.

As a 802.3af compliant device, the Enable-IT 350 48VDC Power over Ethernet Injector uses all 8 wires in a category rated wiring bundle, ie. CAT5e run. As will all PoE voltage drops over distance. As a rule of thumb you will loose 6V per every 100'- 200' of wiring, depending on the gauge. Lower power also means more amperage means more heat and perhaps issues with the 24 gauge wires in CAT5. You may need to use 18 gauge wiring. The Enable-IT 350 is a 48V power injector to maximize your distance and output.

The Enable-350 Power Over Ethernet Injector is suited for the following key environments:

- **Commercial Buildings (Multi-Tenant Units)**
- **Business Parks (Multi-Tenant Units)**
- **Apartments (Multi-Residential Units)**
- **Hotels (Multi-Hospitality Units)**
- **Business Suites (Multi-Hospitality Units)**
- **School Campuses (University, K-12)**
- **College Housing (Multi-Residential Units)**



Figure 1 Enable-IT 350 to a 8424 WiFi PoE Access Point

INSTALLING THE 350 POWER OVER ETHERNET INJECTOR

Unpacking the Enable-IT 350 Power Over Ethernet Injector

Carefully remove the Enable-IT 350 Power Over Ethernet Injector from all packing materials in the box. Verify that the items listed below are present. Make sure that the equipment supplied matches what you ordered. If any items are missing or damaged, please contact your Enable-IT or your distributor for assistance.

- (1) The Enable-IT 350 Power Over Ethernet Injector
- Enable-IT 350 Power Over Ethernet Injector User Manual (this manual)

Performing the On-Site Installation

- ❶ Locate the power source for connecting the supplied power cord and attach this power cord to Enable-IT 350. You can apply power to the unit.
- ❷ Insert a standard Ethernet patch cord to the Data/PoE out port - the other end of the Ethernet Patch cord is for your PoE equipment or Enable-IT 820 PoE and Ethernet Extender (Data/PoE in port)
- ❸ Insert a standard Ethernet patch cord into the Data In port and connect the other end of the Ethernet Patch cord to your Local LAN device such as a switch.



Technical Support

Enable-IT OEM Technical Support is available directly to registered distributors and prospective customers.

Online Technical Services

Enable-IT, Inc. Technical Support is available via e-mail at support@enableit.com

World Wide Web Site

Enable-IT, Inc. Technical Support is available via the Internet at http://www.ethernetextender.com/support/support_overview.php

Returning Products for Warranty Repair

Enable-IT, Inc. warrants to the original purchaser of the Product ("you" or the "End User") that, for the one (1) year period commencing on the date the Product was purchased (the "Warranty Period"), the Product will be substantially free from defects in materials and workmanship under normal use and conditions. Electrical damage is not an item that is covered under this warranty or extended warranties. Optional two (2) year and three (3) year warranties are available to extend this coverage if purchased during the first year of coverage.

If authorized by Enable-IT to return a Product which does not conform to the warranty set forth above, the End User must: (1) obtain a return materials authorization (RMA) number from Enable-IT by contacting the Customer Service Dept. at 888-309-0910 between the hours of 8:00 a.m. and 5:00 p.m. PST and otherwise fully comply with Enable-IT's then-current RMA policy; (2) return the Product to Enable-IT, Inc. in its original packaging freight pre-paid; and (3) provide to Enable-IT the original receipt or bill of sale establishing the date on which the Product was purchased.

Enable-IT Limited Warranty

Enable-IT warrants the Enable-IT 350 Power Over Ethernet Injector solely pursuant to the following terms and conditions.

1. PRODUCT WARRANTY

a. Express Warranty Enable-IT warrants to the original purchaser of the Product ("you" or the "End User") that, for the one (1) year period commencing on the date the Product was purchased (the "Warranty Period"), the Product will be substantially free from defects in materials and workmanship under normal use and conditions. This warranty does not apply to Products which are resold as used, repaired or reconditioned or consumables (such as batteries) supplied with the Product. Enable-IT does not make any warranty with respect to any third party product, software or accessory supplied with or used in connection with the Product and such third party products, software and accessories, if any, are provided "AS IS." Warranty claims related to such third party products, software and accessories must be made to the applicable third party manufacturer.

b. Remedies for Breach of Warranty In the event of a breach of the foregoing warranty, Enable-IT will, in its sole discretion and at its cost and subject to the terms of the following paragraph, repair the non-conforming Product, replace the non-conforming Product with a new or reconditioned Product or refund of the purchase price for the Product. Any new or reconditioned Product provided pursuant to this paragraph is warranted as provided herein for the remainder of the original Warranty Period. THE REMEDY SET FORTH IN THIS PARAGRAPH SHALL BE THE END USER'S SOLE AND EXCLUSIVE REMEDY FOR BREACH OF THE FOREGOING WARRANTY.

c. Conditions for Warranty Qualification If authorized by Enable-IT to return a Product which does not conform to the warranty set forth above, the End User must: (1) obtain a return materials authorization (RMA) number from Enable-IT by contacting the Customer Service Dept. at 888-309-0910 between the hours of 8:00 a.m. and 5:00 p.m. PST and otherwise fully comply with Enable-IT' then-current RMA policy; (2) return the Product to Enable-IT in its original packaging freight pre-paid; and (3) provide to Enable-IT the original receipt or bill of sale establishing the date on which the Product was purchased.

Products returned to Enable-IT without an RMA number will be returned to the End User.

Enable-IT shall not be responsible for damage or loss during shipment of the returned Product to Enable-IT.

d. Voiding of Warranty. The express warranty set forth above shall not apply to failure of the Product if the Product has been subjected to: (i) physical abuse, misuse, improper installation, abnormal use, power failure or surge, or use not consistent with the operating instructions provided by Enable-IT; (ii) modification (including but not limited to opening the Product housing) or repair by any party in any manner other than as approved by Enable-IT in writing; (iii) fraud, tampering, unusual physical or electrical stress, unsuitable operating or physical conditions, negligence or accidents; (iv) removal or alteration of the Product serial number tag; (v) improper packaging of Product returns; or (vi) damage during shipment (other than during the original shipment of the Product to the End User from Enable-IT, if applicable).

e. Warranty Disclaimers THE EXPRESS WARRANTY SET FORTH ABOVE IS IN LIEU OF ALL OTHER WARRANTIES, WHETHER WRITTEN, ORAL, EXPRESS OR IMPLIED. ENABLE-IT DISCLAIMS, TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT OF THIRD PARTY RIGHTS. NO PERSON (INCLUDING WITHOUT LIMITATION, ENABLE-IT' EMPLOYEES, AGENTS, RESELLERS, OEMS OR DISTRIBUTORS) IS AUTHORIZED TO MAKE ANY OTHER WARRANTY OR REPRESENTATION CONCERNING THE PRODUCT. IF THE DISCLAIMER OF ANY IMPLIED WARRANTY IS NOT PERMITTED BY LAW, THE DURATION OF ANY SUCH IMPLIED WARRANTY IS LIMITED TO ONE (1) YEAR FROM THE DATE OF PURCHASE. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY MAY LAST, SO SUCH LIMITATIONS OR EXCLUSIONS MAY NOT APPLY. THIS WARRANTY GIVES THE END USER SPECIFIC LEGAL RIGHTS AND THE END USER MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION. ENABLE-IT DOES NOT WARRANT THAT THE OPERATION OF THE PRODUCT WILL BE UNINTERRUPTED OR ERROR FREE.

ENABLE-IT IS NOT RESPONSIBLE FOR ANY DAMAGE TO OR LOSS OF ANY PROGRAMS, DATA, OR OTHER INFORMATION STORED ON OR TRANSMITTED USING THE PRODUCT.

2. LIMITATION OF LIABILITY IN NO EVENT SHALL ENABLE-IT BE LIABLE TO THE END USER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING OUT OF THE SALE OR USE OF THE PRODUCT (INCLUDING BUT NOT LIMITED TO LOSS OF PROFIT, USE, DATA, OR OTHER ECONOMIC ADVANTAGE), HOWEVER IT ARISES, INCLUDING WITHOUT LIMITATION BREACH OF WARRANTY, OR IN CONTRACT OR IN TORT (INCLUDING NEGLIGENCE), OR STRICT LIABILITY, EVEN IF ENABLE-IT HAS BEEN PREVIOUSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGE AND EVEN IF A LIMITED REMEDY SET FORTH IN THIS AGREEMENT FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL ENABLE-IT' LIABILITY TO THE END USER OR ANY THIRD PARTY EXCEED THE PRICE PAID FOR THE PRODUCT. BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATIONS MAY NOT APPLY TO THE END USER.

3. LICENSE AND LIMITATIONS. The firmware and software embedded in the Product (the "Embedded Software") are licensed to you. Your use of the Product is your acceptance of the warranty terms above and the terms below. You may use the Embedded Software solely in conjunction with your use of the Product. All worldwide right, title and interest in and to the Product, or any portion thereof (including but not limited to the Embedded Software), including all copyrights, patent rights, trademarks, trade secrets, and other intellectual property rights therein and thereto, are and shall remain the exclusive property of Enable-IT and/or its licensors. You acknowledge and agree that you may not, and may not allow any third party to, (i) use the Embedded Software in a manner that is inconsistent with the above express right granted to you or (ii) modify, distribute, reproduce, decompile, disassemble, reverse engineer or otherwise attempt to discover the source code for the Embedded Software.